

Because Microsoft has stopped updating Windows XP the standard installer that we use is no longer working. However you can still install the software on your machine if you follow these simple instructions.

Install.bat is a Windows command script. Before you run it you should check that the referenced files are correct. Right click on the file and select Edit. You can change the variables at the top to a newer version if needed. Once that is done simply copy the file into the same folder as the .msi and launch the .bat file (Preferably as administrator). TCF-S control should install in "C:\Program Files\Optec\TCF-S\Application Files" (or the x86 folder). You may need to create a desktop shortcut to the TCF-S Commander .exe file.

This script might not create the desktop and program menu shortcuts. You can easily create these by hand if you want/need to.