



Radian Raptor 61

f/4.5 Imaging APO Telescope

Electronic Focuser Upgrade

SKU : RT-RAD61-EFOC

Quick-Start Guide



1 Use 2mm hex key to Remove Fine Focus

2 Remove Coarse Focus Knob.



RADIAN

Telescopes



3 Slide Motor knob onto small shaft.
Clamp fits over stainless steel housing.

4 Tighten clamp with 7/64" hex key.
Confirm free movement of
Fine Focus knob.
Tighten Fine Focus Knob.

5 Test Motor—
Rotate to Engage
& Disengage.



7 Attach USB-to-12VDC power cable. Connect to USB hub with 1-amp capacity.

Optionally connect to any 12-volt power source with 2.1 x 5.5mm power plug.

6 Attach standard USB Cable. Connect to control computer.



Download & Install
Radian Raptor 61 electronic focuser Alpaca driver.

Connect and control through any ASCOM client software.



The Radian Raptor 61 electronic focus motor driver functions as an ASCOM Alpaca focuser device for use with any ASCOM client program.

A standalone web client is available for testing and remote control using any smartphone.

Full details available on our download page: <https://bit.ly/3qf7DUE>

